


SPECIFICATIONS

1. Output Power : 15W Max : 3.5 inch
2. Speaker : Come with Play, Stop, Rewind
3. Built in USB / TF MP3 Player and Forward functions
4. Built in Battery : 3.7V 2000Mha Lithium battery
5. Power : Micro USB Type B DC 5V
6. Microphone : 3.5mm mini jack
7. Charging Time : Approximately 3 to 5 hours
8. Operation Time : Approximately 4 to 7 hours (depending on volume)
9. Dimension : 85 x 32 x 92 mm
10. Weight : 210 grams

PACKAGE INCLUDES


1. Portable Voice Amplifier x 1
2. Wired headset microphone x 1
3. USB cable for charging x 1
4. USB Power Adapter x 1
5. Shoulder Strap x 1
6. Belt Clip x 1
7. User Guide x 1

PA-930M



USER'S MANUAL

PARTS DESCRIPTION



1. POWER : To switch ON / OFF the unit
2. MIC IN : Wired headset microphone input
3. VOLUME : Adjust the volume of the unit

NOTE:

Please adjust the microphone closer to the mouth. Please do not cover the microphone with your hands.

If there is feedback, please adjust the volume accordingly.

Safety Guidelines:

- Do not make any modifications to the product, doing so may result in damage to the product.
- Do not expose this equipment and power cord to moisture, dust and sun.
- Keep away from hot apparatus or places with oil, smoke and water.
- Avoid any flammable materials dropping into this equipment.

MUSIC MODE

USB/ TF MP3 Player

- Insert USB Thumb Drive or TF card.
- Press Play Button to play music.
- Press Pause to pause music.

	SHORT PRESS	LONG PRESS
Previous	Previous track	Repeat one
Play/Pause	Play/Pause Playing	ON/OFF
Next	Next track	

Charging the Portable Voice Amplifier

- Please charge the unit using the supplied USB cable with the USB power adapter.
- Charging indicator will turn RED during charging mode.
- RED indicator will dim slightly when the Portable Voice Amplifier is fully charged.

All Products Information and Specifications are subject to changes without prior notice.